




21.1 Design by Omer Arbel PRODUCT SPECIFICATION


© 2010, Bocci Design and Manufacturing Inc. All rights reserved. These drawings and the information contained herein may not be reproduced, communicated to the public, or made available in whole or in part without prior permission. Any inquiries should be directed to the following email address: admin@bocci.ca.







Thread the coaxial cable through canopy.



in the canopy and gently feed the cable through the canopy until you have reached your desired drop length. Use Allen key to tighten the setscrew to 0.5 Nm to hold the strain relief to secure the coaxial cable at its new length. DO NOT OVERTIGHTEN.

Note: The strain relief is a black plastic collar around the coaxial cable. There is a single slot opening on the side of the strain relief component. It is essential that this opening is oriented at 90 degrees to set screw chamber. There can be no contact between the set screw and the cable. - RISK OF ELECTRIC SHORT!

Very carefully uncoil the braided coaxial cable in a spool like manner. Insert your index fingers into opposite sides of the roll then rotate your fingers around each other to unroll the coaxial cable. Use patience: allow the cable to uncoil completely to avoid kinks.

2

Put coaxial cable into the glass trumpet, which then goes into the pendant.


SHALLOW CANOPY


1




© 2010, Bocci Design and Manufacturing Inc. All rights reserved. These drawings and the information contained herein may not be reproduced, communicated to the public, or made available in whole or in part without prior permission. Any inquiries should be directed to the following email address: admin@bocci.ca.

З







5

Connect the coaxial cable to the open slots in the terminal block on the 12V side of the transformer. Ensure that the braided outer wires are all connected to one 12V output wire and all inner insulated wires are connected to the other or a short will occur.

Once all those connections are made, lift the fixture into position and connect the line voltage to the unused matching terminals on the input wires.

6

Tuck the transformer and wiring into the octagonal box, if available, and place canopy cover plate, lining up the fastener holes or connect directly to structural ceiling surface. Affix canopy cover with fasteners provided.

Note: It may be helpful to rest the pendant on a surface higher than its final position so that the canopy may be fastened with greater ease.

7

Bocci 24.1.2 long life bipin xenon lamp included.

Plug the lamp into the socket. Do not touch the lamp with your bare hands.

Purchase replacement lamps online at www.bocci.ca/lamps

Note: When using a dimmer for xenon / halogen, use only low voltage electronic dimmer to ensure the fixture works properly.

8

Turn fixture on.

For additional assistance, please contact Bocci:

BOCCI Vancouver

www.bocci.ca

BOCCI Berlin infoeu@bocci.ca

intoeu@bocci. www.bocci.ca

Made in Vancouver. Canada

Approved to UL standards by CSA



SHALLOW CANOPY



© 2010, Bocci Design and Manufacturing Inc. All rights reserved. These drawings and the information contained herein may not be reproduced, communicated to the public, or made available in whole or in part without prior permission. Any inquiries should be directed to the following email address: admin@bocci.ca.